PrimoAire

Made & Designed For Professionals

PrimoAire Hublay Controller

This wall mounted relay center can control most third party air quality devises base on the PrimoAire Monitor sensor readings and app setting. With the PrimoAire system a homeowner can remotely control and monitor Humidity CO_2, VOC & Dust (Temperature can be monitored but not controlled).

Features

- Mounts on wall, unit or plenum.
- Works with PrimoAire Monitor and app with Apple & Android smart devices.
- Place inside the home, garage, or close to the air handler.
- Pairs with home wi-fi for controlling most air quality devices with 24 volts.
- Dry relays contacts C, N/O, & N/C.
- Indicator lights illuminates to indicate relay is on.
- Encrypted messaging & password for secure connections.
- Input terminals connection for a switch to send a custom alert.
- 2 amp input fuse to protect circuit board.
- On board jumper to turn off relay indicator lights.
- Designed to be purchased & installed by HVAC professionals.

SPECIFICATIONS

SKU#
7HB2D07220

ELECTRICAL RATING
24v AC 60hz
4.7 Watts

DIMENSIONS
6.7 ”W x 6.3”L x 1.6”H

RELAYS
Humidity Relay - Connect de/humidifier.
CO2 Relay - Connect fresh air damper.
VOC Relay - Connect PCO or fresh air damper.
PM2.5(Dust) Relay—Whole home air cleaner.
COMBO/AC Relay - Turns on the AC fan.

WARRANTY
3-Years Parts

Wi-Fi
2.4 GHz

WEIGHT
13.5 oz

STORAGE
-20 F to 130 F (-0 C to 54 C)
0% -90% RH non-condensing

OPERATING HUMIDITY
90% non-condensing max

OPERATING AMBIENT
32 F to 115 F (-0 C to 46 C)

PrimoAire
IAQ Monitor and Contols

20250109